

## 6 Device Programming

### 6.1 In Brief

A wide variety of operating modes permit flexible configuration of drive and automation systems by using positioning, speed and current regulation. The built-in EtherCAT interface allows networking to multiple axes drives as well as online commanding by EtherCAT master units.

#### 6.1.1 Objective

The present Application Note explains typical commanding sequences for different operating modes. The explanations are based on writing/reading commands to access the Object Dictionary. For detailed information on the objects itself → separate document «EPOS3 EtherCAT Firmware Specification» (subsequently referred to as “FwSpec”). For detailed information on the command structure → «EPOS Studio» (command analyzer). For motor-specific data → maxon Catalog.

#### Contents

6.2 First Step .....	6-56
6.3 Homing Mode .....	6-57
6.4 Profile Position Mode .....	6-58
6.5 Profile Velocity Mode .....	6-61
6.6 Interpolated Position Mode (PVT) .....	6-62
6.7 Cyclic Synchronous Position (CSP) .....	6-62
6.8 Cyclic Synchronous Velocity (CSV) .....	6-63
6.9 Cyclic Synchronous Torque (CST) .....	6-64
6.10 State Machine .....	6-65
6.11 Motion Info .....	6-65
6.12 Utilities .....	6-66

#### 6.1.2 Scope

Hardware	Order #	Firmware Version	Reference
EPOS3 EtherCAT		2200h	Firmware Specification
EPOS3 70/10 EtherCAT	411146	2200h or higher	

Table 6-42 Device Programming – covered Hardware and required Documents

#### 6.1.3 Tools

Tools	Description
Software	«EPOS Studio» Version 2.00 or higher

Table 6-43 Device Programming – recommended Tools


## 6.2 First Step

Before the motor will be activated, motor parameters, position sensor parameters and regulation gains must be set. For detailed description → FwSpec.



**Note**

For detailed information on the command structure → «EPOS Studio» (command analyzer).



Object Name	Object	User Value [Default Value]
Motor Type	0x6402-00	Motor-specific [10]
Continuous Current Limit	0x6410-01	Motor-specific [5000]
Pole Pair Number	0x6410-03	Motor-specific [1]
Thermal Time Constant Winding	0x6410-05	Motor-specific [40]
Encoder Pulse Number	0x2210-01	Sensor-specific [500]
Position Sensor Type	0x2210-02	Sensor-specific [1]
Current Regulator P-Gain	0x60F6-01	Motor-specific. Determine optimal parameter using "Regulation Tuning" in «EPOS Studio».
Current Regulator I-Gain	0x60F6-02	
Speed Regulator P-Gain	0x60F9-01	Motor-specific. Determine optimal parameter using "Regulation Tuning" in «EPOS Studio».
Speed Regulator I-Gain	0x60F9-02	
Position Regulator P-Gain	0x60FB-01	Motor-specific. Determine optimal parameter using "Regulation Tuning" in «EPOS Studio».
Position Regulator I-Gain	0x60FB-02	
Position Regulator D-Gain	0x60FB-03	

Table 6-44 Device Programming – First Step

### 6.3 Homing Mode

#### 6.3.1 Start Homing

The axis references to an absolute position using the selected homing method.

	Object Name	Object	User Value [Default Value]
Set Operation Mode	Modes of Operation	0x6060-00	0x06 (Homing Mode)
Set Parameter	Max. Following Error	0x6065-00	User-specific [2000 qc]
	Home Offset	0x607C-00	User-specific [0 qc]
	Max. Profile Velocity	0x607F-00	Motor-specific [25000 rpm]
	Quick Stop Deceleration	0x6085-00	User-specific [10000 rpm/s]
	Speed for Switch Search	0x6099-01	User-specific [100 rpm]
	Speed for Zero Search	0x6099-02	User-specific [10 rpm]
	Homing Acceleration	0x609A-00	User-specific [1000 rpm/s]
	Current Threshold Homing Mode	0x2080-00	User-specific [500 mA]
	Home Position	0x2081-00	User-specific [0 qc]
Set Homing Method	Homing Method	0x6098-00	Select Homing Method (→FwSpec)
Enable Device	Controlword (Shutdown)	0x6040-00	0x0006
	Controlword (Switch-on)	0x6040-00	0x000F
Start Homing	Controlword (Start homing mode)	0x6040-00	0x001F
Homing	Statusword (Homing attained)	0x6041-00	wait until bit 12 is set to "1"
RESET	Controlword (Switch-on)	0x6040-00	0x000F
FINISH			

Table 6-45 Device Programming – Homing Mode (Start)

### 6.3.2 Read Status

Read Statusword

Object Name	Object	User Value [Default Value]
Statusword (Homing attained)	0x6041-00	Home position is reached if bit 12 is set to "1".

Table 6-46 Device Programming – Homing Mode (Read)

### 6.3.3 Stop Positioning

Stop Homing

Object Name	Object	User Value [Default Value]
Controlword (Switch-on) or Controlword (Halt homing)	0x6040-00	0x000F
Controlword (Quick stop)	0x6040-00	0x000B

Table 6-47 Device Programming – Homing Mode (Stop)

## 6.4 Profile Position Mode

### 6.4.1 Set Position

The axis moves to an absolute or relative position using a motion profile (→next page).

	Object Name	Object	User Value [Default Value]				
Set Operation Mode	Modes of Operation	0x6060-00	0x01 (Profile Position Mode)				
	Max. Following Error	0x6065-00	User-specific [2000 qc]				
Set Parameter	Min. Position Limit	0x607D-01	User-specific [-2147483648 qc]				
	Max. Position Limit	0x607D-02	User-specific [2147483647 qc]				
	Max. Profile Velocity	0x607F-00	Motor-specific [25000 rpm]				
	Profile Velocity	0x6081-00	Desired Velocity [1000 rpm]				
	Profile Acceleration	0x6083-00	User-specific [10000 rpm/s]				
	Profile Deceleration	0x6084-00	User-specific [10000 rpm/s]				
	Quick Stop Deceleration	0x6085-00	User-specific [10000 rpm/s]				
	Motion Profile Type	0x6086-00	User-specific [0]				
Enable Device	Controlword (Shutdown)	0x6040-00	0x0006				
	Controlword (Switch-on)	0x6040-00	0x000F				
Set Target Position	Target Position	0x607A-00	Desired Position [qc]				
	Controlword (absolute pos.) or Controlword (absolute pos., start immediately)	0x6040-00	0x001F 0x003F				
Start Positioning	Controlword (relative pos., start immediately) or Controlword (relative positioning)	0x6040-00	0x007F 0x005F				
	<table border="1" style="border-collapse: collapse; width: 100%;"> <tr> <td style="width: 25%; text-align: center;">Abs.</td> <td style="width: 25%; text-align: center;">Abs. + Imm.</td> <td style="width: 25%; text-align: center;">Rel. + Imm.</td> <td style="width: 25%; text-align: center;">Rel.</td> </tr> </table>	Abs.	Abs. + Imm.	Rel. + Imm.	Rel.		
	Abs.	Abs. + Imm.	Rel. + Imm.	Rel.			
	Statusword (set point acknowledge)	0x6041-00	wait until bit 12 is set to "1"				
Controlword (Bit 12 set point acknowledge will be reset)	0x6040-00	0x000F					
Positioning							
RESET							
Read Statusword	Statusword (Target reached)	0x6041-00	wait until bit 10 is set to "1"				
FINISH							

Table 6-48 Device Programming – Profile Position Mode (Set)

### 6.4.2 Read Status

Read Statusword

Object Name	Object	User Value [Default Value]
Statusword (Target reached)	0x6041-00	The axis is at target position if bit 10 is set.

Table 6-49 Device Programming – Profile Position Mode (Read)

### 6.4.3 Stop Positioning

Stop Positioning

Object Name	Object	User Value [Default Value]
Controlword (Stop positioning) or Controlword (Quick stop)	0x6040-00  0x6040-00	0x010F  0x000B

Table 6-50 Device Programming – Profile Position Mode (Stop)

## 6.5 Profile Velocity Mode

### 6.5.1 Start Velocity

Motor shaft rotates with a certain speed with velocity profile.

	Object Name	Object	User Value [Default Value]
Set Operation Mode	Modes of Operation	0x6060-00	0x03 (Profile Velocity Mode)
Set Parameter	Max. Profile Velocity	0x607F-00	Motor-specific [25000 rpm]
	Profile Acceleration	0x6083-00	User-specific [10000 rpm/s]
	Profile Deceleration	0x6084-00	User-specific [10000 rpm/s]
	Quick Stop Deceleration	0x6085-00	User-specific [10000 rpm/s]
	Motion Profile Type	0x6086-00	User-specific [0]
Enable Device	Controlword (Shutdown)	0x6040-00	0x0006
	Controlword (Switch-on)	0x6040-00	0x000F
Set Target Velocity	Target Velocity	0x60FF-00	Velocity for movement [rpm]
Start Move	Controlword	0x6040-00	0x000F

Table 6-51 Device Programming – Profile Velocity Mode (Start)

### 6.5.2 Read Status

	Object Name	Object	User Value [Default Value]
Read Statusword	Statusword (Target velocity reached)	0x6041-00	Target velocity is reached if bit 10 is set.

Table 6-52 Device Programming – Profile Velocity Mode (Read)

### 6.5.3 Stop Velocity

	Object Name	Object	User Value [Default Value]
Stop Velocity	Controlword (Halt Profile Velocity Mode)	0x6040-00	0x010F
	or Controlword (Quick stop)	0x6040-00	0x000B

Table 6-53 Device Programming – Profile Velocity Mode (Stop)

## 6.6 Interpolated Position Mode (PVT)

For detailed information → chapter “4 Interpolated Position Mode” on page 4-31.

## 6.7 Cyclic Synchronous Position (CSP)

### 6.7.1 Set Position

The axis moves to the new absolute position. If the difference between actual and new position is greater than “Max Following Error”, an emergency procedure will be launched.

Object Name	Object	User Value [Default Value]
Modes of Operation	0x6060-00	0x08 (Cyclic Synchronous Position)
Max. Following Error	0x6065-00	User-specific [2000 qc]
Min. Position Limit	0x607D-01	User-specific [-2147483648 qc]
Max. Position Limit	0x607D-02	User-specific [2147483647 qc]
Max. Motor Speed	0x6410-04	Motor-specific
Nominal Current	0x6410-01	Motor-specific (optional)
Motor Torque Constant	0x6410-06	Motor-specific (optional)
Controlword (Shutdown)	0x6040-00	0x0006
Controlword (Switch-on)	0x6040-00	0x000F
<b>Target Position</b>	<b>0x607A-00</b>	<b>New Position [Position units]</b>
Position Offset	0x60B0-00	[Position units] (optional)
Velocity Offset	0x60B1-00	[Velocity units] (optional)
Torque Offset	0x60B2-00	[%o/rated torque] (optional)

Set Operation Mode

↓

Set Parameter

↓

Enable Device

↓

Set Position

Table 6-54 Device Programming – Cyclic Synchronous Position (Set)

### 6.7.2 Stop Positioning

Object Name	Object	User Value [Default Value]
Controlword (Quick stop)	0x6040-00	0x000B

Stop Positioning

Table 6-55 Device Programming – Cyclic Synchronous Position (Stop)



6.8 Cyclic Synchronous Velocity (CSV)

6.8.1 Set Velocity

Motor shaft runs with a certain speed.

Object Name	Object	User Value [Default Value]
Modes of Operation	0x6060-00	0x09 (Cyclic Synchronous Velocity)
<b>Max. Motor Speed</b> Nominal Current Motor Torque Constant	<b>0x6410-04</b> 0x6410-01 0x6410-06	<b>Motor-specific</b> Motor-specific (optional) Motor-specific (optional)
Controlword (Shutdown) Controlword (Switch-on)	0x6040-00 0x6040-00	0x0006 0x000F
<b>Target Velocity</b> Velocity Offset Torque Offset	<b>0x60FF-00</b> 0x60B1-00 0x60B2-00	<b>Velocity per movement [Velocity units]</b> [Velocity units] (optional) [%/rated torque] (optional)

Table 6-56 Device Programming – Cyclic Synchronous Velocity (Set)

6.8.2 Stop Velocity

Object Name	Object	User Value [Default Value]
Controlword (Quick stop)	0x6040-00	0x000B

Table 6-57 Device Programming – Cyclic Synchronous Velocity (Stop)

## 6.9 Cyclic Synchronous Torque (CST)

### 6.9.1 Set Torque

This command applies a certain torque at the motor.

Object Name	Object	User Value [Default Value]
Set Operation Mode	Modes of Operation	0x6060-00 0x0A (Cyclic Synchronous Torque)
Set Parameter	Nominal Current Nominal Motor Speed Motor Torque Constant	0x6410-01 0x6410-04 0x6410-06 Motor-specific Motor-specific Motor-specific
Enable Device	Controlword (Shutdown) Controlword (Switch-on)	0x6040-00 0x6040-00 0x0006 0x000F
Set Torque	<b>Target Torque</b> Torque Offset	<b>0x6071-00</b> 0X60B2-00 [%/rated torque] [%/rated torque] (optional)

```

graph TD
    A[Set Operation Mode] --> B[Set Parameter]
    B --> C[Enable Device]
    C --> D[Set Torque]
    style D stroke-dasharray: 5 5
  
```

Table 6-58 Device Programming – Cyclic Synchronous Torque (Set)

### 6.9.2 Stop Motion

Object Name	Object	User Value [Default Value]
Stop Torque	Controlword (Quick stop)	0x6040-00 0x000B

Table 6-59 Device Programming – Cyclic Synchronous Torque (Stop)

## 6.10 State Machine

### 6.10.1 Clear Fault

Resetting "Fault" condition sends the Controlword with value 0x0080.

Clear Fault

Object Name	Object	User Value [Default Value]
Controlword (Fault Reset)	0x6040-00	0x0080

Table 6-60 Device Programming – State Machine (Clear Fault)

## 6.11 Motion Info

### 6.11.1 Get Movement State

Read Statusword

Object Name	Object	User Value [Default Value]
Read Statusword	0x6041-00	Bit 10 tells states that target is reached. For details → FwSpec.

Table 6-61 Device Programming – Motion Info (Get Movement State)

### 6.11.2 Read Position

Read Position

Object Name	Object	User Value [Default Value]
Position actual value	0x6064-00	[Position units]

Table 6-62 Device Programming – Motion Info (Read Position)

### 6.11.3 Read Velocity

Read Velocity

Object Name	Object	User Value [Default Value]
Velocity actual value	0x 606C-00	[Velocity units]

Table 6-63 Device Programming – Motion Info (Read Velocity)

### 6.11.4 Read Current

	Object Name	Object	User Value [Default Value]
Read Torque	Torque actual value	0x6077-00	[%o/rated torque]

Table 6-64 Device Programming – Motion Info (Read Current)

## 6.12 Utilities

### 6.12.1 Store all Parameters

Saves all parameters.

	Object Name	Object	User Value [Default Value]
Store	Save All Parameters	0x10101-01	0x65766173 “save”

Table 6-65 Device Programming – Utilities (Store all Parameters)

### 6.12.2 Restore all default Parameters

Restores all parameters to factory settings.

	Object Name	Object	User Value [Default Value]
Restore	Restore All Default Parameters	0x1011-01	0x64616F6C “load”

Table 6-66 Device Programming – Utilities (Restore all default Parameters)